

Electric part-turn actuators

SG 05.1 – SG 12.1 SGR 05.1 – SGR 12.1 AUMA NORM





Operation instructions

Scope of these instructions:	These instructions are valid for part-turn actuators of the type ra 05.1 – SG 12.1 and SGR 05.1 – SGR 12.1 in version AUMA NO These operation instructions are only valid for "clockwise closing driven shaft turns clockwise to close the valve.	DŘM.
Table of contents		Page
1. Safety instructions		Page 4
1.1 Range of application		4
1.2 Commissioning (elec	strical connection)	4
1.3 Maintenance1.4 Warnings and notes		4 4
2. Short description		4
3. Technical data		5
4. Transport, storage and pa	ackaging	7
4.1 Transport		7
4.2Storage4.3Packaging		7 7
5. Manual operation		8
6. Mounting to valve		9
7. Electrical connection		10
	/IA plug/ socket connector	10
7.2 Delay time7.3 Controls made by AL	INA	10 11
7.4 Heater		11
7.5 Motor protection		11
7.6 Remote position tran7.7 Limit and torgue swit		11 11
7.7 Limit and torque swit7.8 Fitting the cover	ches	11
8. Setting of end stops for p	art-turn actuators on butterfly valves	12
8.1 Setting end stop CLC		12
8.2 Setting end stop OPI 8.3 Setting limit switching		12 12
	part-turn actuators on ball valves	13
9.1 Setting end stop OPI		13
9.2 Setting end stop CLC		13
9.3 Setting limit switching	-	13
10.Changing the swing angle10.1Increasing the swing		14 14
10.2 Reducing the swing a	-	14
11. Opening the switch comp		15
	from the switch compartment	15
11.2 Pulling off the indicat12. Setting the limit switching		15 16
	CLOSED (black section)	16
	OPEN (white section)	16
12.3 Checking the limit sw		16
13.Setting the DUO limit swit13.1Setting direction CLC		17 17
13.2 Setting direction OPE		17
13.3 Checking the DUO lin		17

			Page		
14.	Setti	ng the torque switching	18		
14.1 14.2		Setting Checking the torque switches	18 18		
15.	Test	run	19		
15.1		Checking the direction of rotation	19		
15.2		Checking the limit switching	19		
16.	Setti	ng the potentiometer (option)	20		
17.	Setti	ng the electronic position transmitter RWG (option)	21		
17.1 17.2		Setting 2-wire system 4 – 20 mA and 3- /4-wire system 0 – 20 mA	22 23		
	Cotti	Setting 3- / 4- wire system 4 – 20 mA			
18.		ng the operating time	24		
19.		ng the mechanical position indicator	25 25		
20.	20. Closing the switch compartment				
21.	Enclo	sure protection IP 68 (option)	26		
22.	Appli	cations in Ex zone 22 (option)	27		
23.	Main	tenance	28		
24.	Lubri	cation	28		
25.	Dispo	osal and recycling	29		
26.	Servi	се	29		
27.	Spare	e parts list Multi-turn actuator SG(R) 05.1 - SG(R) 12.1 with plug/ socket connector	32		
28.	Decla	aration of Conformity and Declaration of Incorporation	34		
	Index		35		
	Addr	esses of AUMA offices and representatives	36		

1.	Safety instructions	
1.1	Range of application	AUMA actuators are designed for the operation of industrial valves, e.g. butterfly valves and ball valves. For other applications, please consult us. The manufacturer is not liable for any possible damage resulting from use in other than the designated appli- cations. Such risk lies entirely with the user. Observance of these operation instructions is considered as part of the actuator's designated use.
1.2	Commissioning (electrical connection)	During electrical operation, certain parts inevitably carry lethal voltages. Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules.
1.3	Maintenance	The maintenance instructions (refer to page 28) must be observed, other- wise a safe operation of the actuator is no longer guaranteed.
1.4	Warnings and notes	Failure to observe the warnings and notes may lead to serious injuries or damage. Qualified personnel must be thoroughly familiar with all warnings and notes in these operation instructions. Correct transport, proper storage, mounting and installation, as well as careful commissioning are essential to ensure a trouble-free and safe oper- ation. During operation, the multi-turn actuator warms up and surface tempera- tures > 60 °C may occur. Check the surface temperature prior to contact in order to avoid burns.
		The following references draw special attention to safety-relevant proce- dures in these operation instructions. Each is marked by the appropriate pictograph.
		This pictograph means: Note! "Note" marks activities or procedures which have major influence on the correct operation. Non-observance of these notes may lead to consequen- tial damage.
		This pictograph means: Electrostatically endangered parts! If this pictograph is attached to a printed circuit board, it contains parts which may be damaged or destroyed by electrostatic discharges. If the boards need to be touched during setting, measurement, or for exchange, it must be assured that immediately before a discharge through contact with an earthed metallic surface (e.g. the housing) has taken place.
	\triangle	This pictograph means: Warning! "Warning" marks activities or procedures which, if not carried out correctly, can affect the safety of persons or material.
2.	Short description	AUMA part-turn actuators type SG 05.1 – SG 12.1 and SGR 05.1 – SGR 12.1 have a modular design. The part-turn actuators are driven by an electric motor. A handwheel is provided for manual operation. The limitation of travel is realised via limit switches in both end positions. Torque seating is also possible in both end positions. The type of seating is determined by the valve

normal operation.

manufacturer. Additionally, a mechanical end stop is provided for the protection of the valve. This is not, however, designed to be approached during

3. Technical data

Part-turn actuators AUMA NORM require external controls. AUMA offers actuator controls AUMA MATIC AM or AUMATIC AC. These can also easily be mounted to the actuator at a later date.

Features and functions			
Type of duty 1)	SG:	Short time duty S2 - 15 min	
	SGR:	Intermittent duty S4 - 25 %	
Motors	Standard: Options:	3-ph AC asynchronous motor, type IM B9 according to IEC 34 (SG and SGR) 1-phase AC motor (SG only) DC shunt motor (SG only)	
Insulation class	Standard: Option:	F, tropicalized H, tropicalized (3-phase AC motors only)	
Motor protection	Standard: Option:	Thermoswitches (NC) (DC motors without motor protection) PTC thermistors (according to DIN 44082)	
Self-locking	ves		
Swing angle	Standard: Options:	80° to 110° adjustable between min. and max. value. 30° – 40°, 40° – 55°, 55° – 80°, 110° – 160°, 160° – 230° or 230° – 320°	
Limit switching	Counter gear Standard: Options:	mechanism for end positions CLOSED and OPEN Single switch (1 NC and 1 NO) for each end position Tandem switch (2 NC and 2 NO) for each end position, switches galvanically isolated Triple switch (3 NC and 3 NO) for each end position, switches galvanically isolated Intermediate position switch (DUO limit switching), available for any intermediate position	
Torque switching	infinitely adjust Standard: Options:	able torque switching for direction OPEN and CLOSE Single switch (1 NC and 1 NO) for each direction Tandem switch (2 NC and 2 NO) for each direction, switches galvanically isolated	
Non-intrusive setting (option)	Magnetic limit and torque transmitter MWG (only possible in combination with actuator controls AUMATIC)		
Position feedback signal, analogue (options)	Potentiometer or 0/4 – 20 mA (RWG) For further details see separate data sheet		
Torque feedback signal, analogue (option)	Only in comb	ination with magnetic limit and torque transmitter MWG and controls	
Mechanical position indicator	Continuous ir	ndication, adjustable indicator disc with symbols OPEN and CLOSED	
Running indication (option)	Blinker transr	nitter	
Heater in switch compartment	Standard: Options: A resistance the actuator of	self-regulating PTC heater, $5 - 20$ W, $110 - 250$ V AC/ DC 24 - 48 V AC/ DC or 380 - 400 V AC type heater (5 W, 24 V DC) is installed within the actuator in combination with controls AM or AC.	
Motor heater (option)	12.5 W		
Manual operation	electrical ope		
Electrical connection		Handwheel lockable	
Threads for cable glands	Standard:	connector with screw type connection Metric threads	
Theads for caple yidnus	Options:	Pg-threads, NPT-threads, G-threads	
Terminal plan	KMS TP 100	001 (basic version with 3-phase AC motor)	
Splined coupling for connection to the valve shaft	Standard: Options:	Coupling without bore Machined coupling with bore and keyway, square bore or bore with two-flats according to EN ISO 5211	

Service conditions			
Enclosure protection according to EN 60 529 ²⁾	Standard: Options:	IP 68-	DS (Double Sealed) DS (Double Sealed) le Sealed: = terminal compartment additionally sealed against interior)
Corrosion protection	Standard:	KN	Suitable for installation in industrial units, in water or power plants with a low pollutant concentration
	Options:	KS KX	Suitable for installation in occasionally or permanently aggressive atmosphere with a moderate pollutant concentration (e.g. in wastewater treatment plants, chemical industry) Suitable for installation in extremely aggressive atmosphere with high humidity and high pollutant concentration
		KX-G	same as KX, however aluminium-free version (outer parts)
Finish coating	Standard:	Two-c	omponent iron-mica combination
Standard colour	Standard:	•••	DB 702, similar to RAL 9007)
	Option:		colours are possible on request
Ambient temperature 3)	Standard SG		- 25 °C to + 80 °C (with 3-phase AC motor)
		-	-25 °C to $+70$ °C (with 1-phase AC and DC motor)
	Standard SG	K:	-25 °C to $+60$ °C (with 3-phase AC motor)
	Options:		-40 °C to $+60$ °C (low temperature)
	current only)		- 50 °C to + 60 °C (extreme low temperature) (SG with 3-phase AC
Lifetime	SG 05.1/ SG	07.1:	20,000 operating cycles (OPEN - CLOSE - OPEN) for 90°
	SG 10.1:		15,000 operating cycles (OPEN - CLOSE - OPEN) for 90°
	SG 12.1:		10,000 operating cycles (OPEN - CLOSE - OPEN) for 90°
	SGR 05.1 – 1	2.1: ⁴⁾	min. 2.5 million operations (control steps)
Other information			
EU Directives	Electromagne	etic Cor	npatibility (EMC): (89/336/EEC)
	Low Voltage Directive: (73/23/EEC)		e: (73/23/EEC)
	Machinery Di	rective:	(98/37/EC)
Reference documents	Product description "Electric part-turn actuators SG" Dimension sheets SG Electrical data SG/ SGR		

2) For version in enclosure protection IP 68, higher corrosion protection KS or KX is strongly recommended Additionally, for enclosure protection IP 68, we recommend to use the double sealed terminal compartment DS

3) Version with RWG min. – 40 $^\circ C$ and max. + 70 $^\circ C$

4) The lifetime depends on the load and the number of starts. A high starting frequency will rarely improve the modulating accuracy. To reach the longest possible maintenance and fault-free operation time, the number of starts per hour chosen should be as low as permissible for the process


4. Transport, storage and packaging

4.1 Transport

- For transport to place of installation, use sturdy packaging.
- Do not attach ropes or hooks to the handwheel for the purpose of lifting by hoist.
- If part-turn actuator is mounted on valve, attach ropes or hooks for the purpose of lifting by hoist to valve and not to part-turn actuator.

Fitting the ball handle: To avoid damage during transport, the ball handles are fitted to the inside of the handwheel. Prior to commissioning, the ball handle has to be fitted in the correct position.

- Remove cap nut (figure 1).
- Pull out ball handle and re-insert in correct position.
- Fasten with cap nut.
- Remove label from the hand wheel for fitting the ball handle.



4.2 Storage

- Store in well-ventilated, dry room.
- Protect against floor dampness by storage on a shelf or on a wooden pallet.
- Cover to protect against dust and dirt.
- Apply suitable corrosion protection agent to bright surfaces.

If part-turn actuators are to be stored for a long time (more than 6 months), the following points must be observed additionally:

- Prior to storage: Protect bare surfaces, in particular the output drive parts and mounting surface, with long-term corrosion protection agent.
- Check for corrosion approximately every 6 months. If first signs of corrosion show, apply new corrosion protection.



After mounting, connect part-turn actuator immediately to electrical mains, so that condensation is prevented by the heater.

Our products are protected by special packaging for the transport ex works. The packaging consists of environmentally friendly materials which can easily be separated and recycled.

We use the following packaging materials: wood, cardboard, paper, and PE foil. For the disposal of the packaging material, we recommend recycling and collection centres.

4.3 Packaging

5. Manual operation

The actuator may be operated manually for purposes of setting and commissioning, and in case of motor failure or power failure.

Engaging manual operation:

Manual operation is activated by pulling at the handwheel. A change-over is not required. The handwheel does not rotate during motor operation.



- Turning the handwheel during motor operation results in an extension or reduction of the operating time, depending on the direction of rotation.
 - It is not necessary to use an extension for manual operation. Excessive force may cause damage.

Disengaging manual operation: Release handwheel.

Handwheel has to engage.

6. Mounting to valve



- Prior to mounting, the part-turn actuator must be checked for any damage. Damaged parts must be replaced by original spare parts.
- After mounting, check part-turn actuator for damage to paint finish. If damage to paint-finish has occurred after mounting, it has to be touched up to avoid corrosion.
- For **butterfly valves**, the recommended mounting position is end position CLOSED

(Prior to mounting, bring the part-turn actuator to the mechanical end stop CLOSED by turning the handwheel clockwise.).

- For **ball valves** the recommended mounting position is end position OPEN (Prior to mounting, bring the part-turn actuator to the mechanical end stop OPEN by turning the handwheel counterclockwise.).
- Thoroughly degrease mounting faces of part-turn actuator and valve.
- Apply a small quantity of grease to the valve shaft.
- Place coupling sleeve onto valve shaft and secure (refer to figure 2, detail A or B), ensure that dimensions X, Y and Z are observed (refer to table 1).
- Apply non-acidic grease at splines of coupling.
- Fit actuator so that fixing holes in actuator and valve mounting flange are in alignment.

If necessary, move actuator up or down one tooth on the coupling. If required, turn handwheel/ crank a little in direction OPEN or CLOSE until holes align to the threads.

- Ensure that the spigot (if provided) mates uniformly in the recess and that the mounting faces are in complete contact.
- Fasten the actuator with bolts of minimum quality 8.8 using lock washers. Fasten bolts evenly crosswise to the appropriate torque according to table 1.




Table 1: Dimensions for couplings/ fastening torques for bolts


Туре	X max.	Y max.	Z max.	8.8	T _A [Nm]
SG(R) 05.1-F05	5	3	60	4 x M 6	11
SG(R) 05.1-F07	5	3	60	4 x M 8	25
SG(R) 07.1-F07	7	3	60	4 x M 8	25
SG(R) 07.1-F10	7	3	60	4 x M 10	51
SG(R) 10.1-F10	10	3	77	4 x M 10	51
SG(R) 10.1-F12	10	3	77	4 x M 12	87
SG(R) 12.1-F12	10	6	100	4 x M 12	87
SG(R) 12.1-F14	10	6	100	4 x M 12	87

7. Electrical connection



Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules.

7.1 Connection with AUMA plug/ socket connector



- Check whether type of current, supply voltage, and frequency comply with motor data (refer to name plate at motor).
- Loosen bolts (50.01) (figure 3) and remove plug cover.
- Loosen screws (51.01) and remove socket carrier (51.0) from plug cover (50.0).
- Insert cable glands suitable for connecting cables (The enclosure protection stated on the name plate is only ensured if suitable cable glands are used.).
- Seal cable entries which are not used with suitable plugs.
- Connect cables according to order-related terminal plan.
- The terminal plan pertaining to the part-turn actuator is attached to the handwheel in a weather-proof bag, together with the operation instructions. In case the terminal plan is not available, it can be obtained from AUMA (state commission no., refer to name plate) or downloaded directly from the Internet (www.auma.com).

Figure 4: Parking frame (accessory)

A special parking frame (figure 4) for protection against touching the bare contacts and against environmental influences is available.

Table 2: Technical data AUMA plug/ socket connector					
Technical data	Power terminals ¹⁾	Protective earth	Control terminals		
No. of contacts max.	6 (3 are used)	1 (leading contact)	50 pins/ sockets		
Marking	U1, V1, W1, U2, V2, W2	ŧ	1 to 50		
Connecting voltage max.	750 V	-	250 V		
Current max.	25 A	-	16 A		
Type of customer connection	Screws	Screw for ring lug	Screws		
Cross section max.	6 mm ²	6 mm ²	2.5 mm ²		
Material: Pin/ socket carrier	Polyamide	Polyamide	Polyamide		
Contacts	Brass (Ms)	Brass (Ms)	Brass, tin plated or gold plated (option)		
1) Suitable for copper wires. For aluminium wires, please contact AUMA					


7.2 Delay time

The delay time is the time from the tripping of the limit or torque switches to the motor power being removed. To protect the valve and the actuator, we recommend a delay time < 50 ms. Longer delay times are possible provided the operating time, output drive type, valve type, and the type of installation are considered.

We recommend to switch off the corresponding contactor directly by the limit or torque switch.

7.3	Controls made by AUMA	In case the required reversing contactors are not to be installed in the control cabinet, the controls AUMA MATIC or AUMATIC can easily be mounted to the actuator at a later date. For enquiries and more information, please state our commission no. (refer to actuator name plate).
7.4	Heater	AUMA part-turn actuators have a heater installed as standard. To prevent condensation, the heater must be connected.
7.5	Motor protection	In order to protect against overheating and impermissibly high temperatures at the actuator, PTC thermistors or thermoswitches are embedded in the motor winding. The thermoswitch is tripped as soon as the max. permissible winding temperature has been reached.
		Failure to integrate PTC thermistors or thermoswitches into the control circuit voids the warranty for the motor.
7.6	Remote position transmitter	For the connection of remote position transmitters (potentiometer, RWG), screened cables must be used.

7.7 Limit and torque switches



7.8 Fitting the cover

Only the same potential can be switched on the two circuits (NC/ NO contact) of a limit or torque switch. If different potentials are to be switched simultaneously, tandem switches are required.

To ensure correct signalisation, the leading contacts of the tandem switches must be used for that purpose and the lagging contacts for switching off.

Table 3: Technical data limit/ torque switches			
NO NC NC NO	Mechanical life time = 2 x 10 ⁶ starts		
Type of current	Switch rating I _{max}		
	30 V	125 V	250 V
1-phase AC (ind. load) cos phi = 0.8	5 A	5 A	5 A
DC (resistive load)	2 A	0.5 A	0.4 A
with gold plated contacts	min. 5 V, max. 50 V		
Current	min. 4 mA, max. 400 mA		

After connection:

- Insert the socket carrier (51.0) into the plug cover (50.0) and fasten it with screws (51.01).
- Clean sealing faces at the plug cover and the housing.
- Check whether O-ring is in good condition.
- Apply a thin film of non-acidic grease (e.g. Vaseline) to the sealing faces.
- Replace plug cover (50.0) and fasten bolts (50.01) evenly crosswise.
- Fasten cable glands with the specified torque to ensure the required enclosure protection.

8. Setting the end stops for part-turn actuators on butterfly valves

For actuators on ball valves refer to page 13, clause 9.

The settings can only be performed if the valve has not yet been mounted in a pipeline.




- If part-turn actuators are supplied without a valve: hex. bolts (03, figure 6) are not fastened.
- If part-turn actuators are supplied with a valve: hex. bolts (03, figure 6) are fastened.
 End stops and limit switching have already been set and only have to be checked.
- 8.1 Setting end stop CLOSED
- If hex. bolts (03, figure 6) are fastened: loosen by approx. 3 turns.
- Turn handwheel clockwise (closing direction), until valve is closed (end position CLOSED).
 Check whether end stop (10) has rotated, otherwise turn end stop (10) clockwise up to the stop.
- In case end position CLOSED has been passed: reverse several turns at the handwheel and approach end position again.
 Turn end stop (10) by 1/8 a turn counterclockwise.
 - (Protective cap (16) must not be loosened in the process).



The end stops are designed for the protection of the valve. They have to be set as to ensure that they are not used during normal operation.

• Fasten hex. bolts (03) crosswise with torque 25 Nm.



8.2 Setting end stop OPEN

CLOSĚD

Setting limit switching

The swing angle has been set in the factory. Therefore, the end stop OPEN need not be set.

After setting the end stop CLOSED, the limit switching for end position CLOSED can be set immediately (page 16, clause 12.). For this, the switch compartment has to be opened and the indicator disc has to be removed (refer to page 15, clause 11.).

8.3

9. Setting the end stops for part-turn actuators on ball valves

For actuators on butterfly valves refer to page 12, clause 8.

The settings can only be performed if the valve has not yet been mounted in a pipeline.



• If part-turn actuators are supplied without a valve:

End stops and limit switching have already been set and

• If part-turn actuators are supplied with a valve:

hex. bolts (03, figure 7) are not fastened.

hex. bolts (03, figure 7) are fastened.

- 9.1 Setting end stop OPEN
- If hex. bolts (03, figure 7) are fastened: loosen by approx. 3 turns.


only have to be checked.

- Turn handwheel counterclockwise (opening direction), until valve is open (end position OPEN).
 Check whether end stop (10) has rotated, otherwise turn end stop (10) counterclockwise up to the stop.
- In case end position OPEN has been passed: reverse several turns at the handwheel and approach end position OPEN again.
- Turn end stop (10) by 1/8 a turn clockwise. (Protective cap (16) must not be loosened in the process).



The end stops are designed for the protection of the valve. They have to be set as to ensure that they are not used during normal operation.

• Fasten hex. bolts (03) crosswise with torque 25 Nm.



9.2 Setting end stop CLOSED

The swing angle has been set in the factory. Therefore, the end stop CLOSED need not be set.

9.3 Setting limit switching OPEN After setting the end stop OPEN, the limit switching for end position OPEN can be set immediately (page 16, clause 12.). For this, the switch compartment has to be opened and the indicator disc has to be removed (refer to page 15, clause 11.).

10.	Changing the swing angle	The swing angle only has to be changed, if the swing range for setting the end stops (clauses 8. and 9.) is not sufficient.
		Unless ordered otherwise, the swing angle is set to 90°. In the standard version, the swing angle can be adjusted within the range of 80° to 110°. For optional swing angle ranges, refer to Technical data, page 5.
10.1	Increasing the swing angle	 Unscrew protective cap (16) (figure 8). While holding end stop nut (2.4) in position with open end wrench (19 mm), remove grub screw (2.02). Turn end stop nut (2.4) counterclockwise.

- Turn end stop nut (2.4) counterclockwise. Do not exceed dimension A max. (table 4).
- Move valve manually to the desired end position OPEN.
- Turn end stop nut (2.4) clockwise until it is tight up to the stop nut (7).
- Degrease face of grub screw (2.02).
- Hold end stop nut in position (2.4) with open end wrench (19 mm) and fasten grub screw (2.02) with torque 85 Nm.
- Check O-ring (016) and replace if damaged.
- Replace protective cap (16).




Table 4				
Туре	A min. [mm]	A max. [mm]		
SG 05.1/ SGR 05.1	10	22		
SG 07.1/ SGR 07.1	10	22		
SG 10.1/ SGR 10.1	8	17		
SG 12.1/ SGR 12.1	12	23		

10.2 Reducing the swing angle

- Unscrew protective cap (16) (figure 8).
- While holding end stop nut (2.4) in position with open end wrench (19 mm), remove grub screw (2.02).
 Move valve into the desired end position OPEN.
- Turn end stop nut (2.4) clockwise until it is tight up to the stop nut (7) and do not fall below dimension A min.
- Degrease face of grub screw (2.02).
- Hold end stop nut in position (2.4) with open end wrench (19 mm) and fasten grub screw (2.02) with torque 85 Nm.
- Check O-ring (016) and replace if damaged.
- Replace protective cap (16).

11. Opening the switch compartment

To be able to carry out the following settings (clauses 12. to 18.), the switch compartment must be opened and the indicator disc must be removed.

These settings are only valid for "clockwise closing", i.e. driven shaft turns clockwise to close the valve.




Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules.

- 11.1 Removing the cover from the switch compartment
 - Remove 4 bolts and take off the cover at the switch compartment (figure 9).




- 11.2 Pulling off the indicator disc
- Pulling off the indicator disc (figure 10). Open end wrench (approx. 14 mm) may be used as lever.



12. Setting the limit switching

12.1 Setting end position CLOSED (black section)

- Turn handwheel clockwise until valve is closed.
- To prevent that the end stop is reached (due to overrun) before the limit switch has tripped, turn handwheel 4 turns (overrun) in clockwise direction. During test run check overrun and, if necessary, correct setting of the limit switching.
- **Press down** and turn setting spindle A (figure 11) with screw driver (5 mm) in direction of arrow, thereby observe pointer B. While a ratchet is felt and heard, the pointer B moves 90° every time. When pointer B is 90° from mark C, continue turning slowly. When pointer B has reached the mark C, stop turning and release setting spindle. If you override the tripping point inadvertently (ratchet is heard after the pointer has snapped), continue turning the setting spindle in the same direction and repeat setting process.



12.2 Setting end position OPEN (white section)

- Turn handwheel counterclockwise until valve is open.
- To prevent that the end stop is reached (due to overrun) before the limit switch has tripped, turn handwheel 4 turns (overrun) in clockwise direction. During test run check overrun and, if necessary, correct setting of the limit switching.
- **Press down** and turn setting spindle D (figure 11) with screw driver (5 mm) in direction of arrow, thereby observe pointer E. While a ratchet is felt and heard, the pointer E moves 90° every time. When pointer E is 90° from mark F, continue turning slowly. When pointer E has reached the mark F, stop turning and release setting spindle. If you override the tripping point inadvertently (ratchet is heard after the pointer has snapped), continue turning the setting spindle in the same direction and repeat setting process.
- **12.3 Checking the limit switches** The red test buttons T and P (figure 11) are used for manual operation of the limit switches.
 - Turning T in direction of the arrow LSC (WSR) triggers limit switch CLOSED.
 - Turning P in direction of the arrow LSO (WOEL) triggers limit switch OPEN.

13. Setting the DUO limit switching (option)


Any application can be switched on or off via the two intermediate position switches.



For setting, the switching point (intermediate position) must be approached from the same direction as afterwards in electrical operation.

13.1 Setting direction CLOSE (black section)

- Move valve to desired intermediate position.
- **Press down** and turn setting spindle G (figure 12) with screw driver (5 mm) in direction of arrow, while observing pointer H. While a ratchet is felt and heard, the pointer H moves 90° every time. When pointer H is 90° from mark C, continue turning slowly. When pointer H has reached the mark C, stop turning and release setting spindle. If you override the tripping point inadvertently (ratchet is heard after the pointer has snapped), continue turning the setting spindle in the same direction and repeat setting process.



13.2 Setting direction OPEN (white section)

- Move valve to desired intermediate position.
- **Press down** and turn setting spindle K (figure 12) with screw driver (5 mm) in direction of arrow, while observing pointer L. While a ratchet is felt and heard, the pointer L moves 90° every time. When pointer L is 90° from mark F, continue turning slowly. When pointer L has reached the mark F, stop turning and release setting spindle. If you override the tripping point inadvertently (ratchet is heard after the pointer has snapped), continue turning the setting spindle in the same direction and repeat setting process.

The red test buttons T and P (figure 12) are used for manual operation of the DUO limit switches.


- Turning T in direction of the arrow TSC (DSR) triggers DUO limit switch CLOSED. The torque switch CLOSED is actuated at the same time.
- Turning P in direction of the arrow TSO (DOEL) triggers DUO limit switch OPEN. The torque switch OPEN is actuated at the same time.

13.3 Checking the DUO limit switches

14. Setting the torque switching

14.1 Setting

- The set torque must suit the valve!
- This setting must only be changed with the consent of the valve manufacturer!



- Loosen both lock screws O at the torque dial (figure 13).
- Turn torque dial P to set it to the required torque (1 da Nm = 10 Nm). Example:
 - Figure 13 shows the following setting:
 - 11.5 da Nm = 115 Nm for direction CLOSE
- 12.5 da Nm = 125 Nm for direction OPEN
- Tighten lock screws O again



- The torque switches can also be operated in manual operation.
- The torque switching acts as overload protection over full travel, also when stopping in the end positions by limit switching.

14.2 Checking the torque switches The red test buttons T and P (figure 11) are used for manual operation of the torque switches:


- Turning T in direction of the arrow TSC (DSR) triggers torque switch CLOSED.
- Turning P in direction of the arrow TSO (DOEL) triggers torque switch OPEN.
- If a DUO limit switching (optional) is installed in the actuator, the intermediate position switches will be operated at the same time.

15. Test run

15.1 Checking the direction of rotation

• Place indicator disc on shaft.

The direction of rotation of the indicator disc (figure 14) indicates the direction of rotation of the output drive.



- Move actuator manually to intermediate position or to sufficient distance from end position.
- Switch on actuator in running direction CLOSE and observe the direction of rotation:

If the indicator disc turns clockwise, the direction of rotation is correct.



If the direction of rotation is wrong, switch off immediately Correct phase sequence at motor connection. Repeat test run.

- 15.2 Checking the limit switching
- Move actuator manually into both end positions of the valve.
- Check whether limit switching is set correctly. Hereby observe that the appropriate switch is tripped in each end position and released again after the direction of rotation is changed. If this is not the case, the limit switching must first be set, as described from page 16.
- If no other options (clauses 16. to 18.) require setting:
- Close switch compartment (see page 24, clause 19.).


16. Setting the potentiometer (option)

- For remote indication -
- Move valve to end position CLOSED.
- Pull off indicator disc.
- Turn potentiometer (E2) counterclockwise until stop is felt.
- End position CLOSED corresponds to 0 %, end position OPEN to 100 %.
- Turn potentiometer (E2) back a little.



Due to the ratio of the reduction gearings for the position transmitter, the complete resistance range is not always utilized for the whole travel. Therefore, an external possibility for adjustment (setting potentiometer) must be provided.

• Perform fine-tuning of the zero point at external setting potentiometer (for remote indication).




17. Setting the electronic position transmitter RWG (option)

- For remote indication or external control -

After mounting the part-turn actuator to the valve, check setting by measuring the output current (see subclauses 17.1 or 17.2) and re-adjust, if necessary.

Table 5: Technical data RWG 4020					
Terminal plans		KMS TP4 /	KMS TP _ 4 _ / KMS TP _ 5 _ /		
		3- or 4- wire system	2-wire system		
Output current	la	0 – 20 mA, 4 – 20 mA	4 – 20 mA		
Power supply	$U_{\rm v}$	24 V DC, ±15 % smoothed	14 V DC + (I x R _B), max. 30 V		
Max. input cur- rent	Ι	24 mA at 20 mA output current	20 mA		
Max. load	R_B	600 Ω	(Uv - 14 V) / 20 mA		

The position transmitter board (figure 16) is located under the cover plate (figure 17).




17.1 Setting 2-wire system 4 – 20 mA and 3- /4-wire system 0 – 20 mA

- Connect voltage to electronic position transmitter.
- Move valve to end position CLOSED.
- Pulling off the indicator disc.
- Connect ammeter for 0 20 mA to measuring points (figure 17).



The circuit (external load) must be connected (observe max. load R_B), or the appropriate poles at the terminals (refer to wiring diagram) must be linked, otherwise no value can be measured.

- Turn potentiometer (E2) counterclockwise until stop is felt.
- Turn potentiometer (E2) slightly back.



- Turn potentiometer "0" clockwise until output current starts to increase.
- Turn potentiometer "0" back until the following value is reached: for 3- or 4-wire system: approx. 0.1 mA for 2-wire system: approx. 4.1 mA. This ensures that the signal remains above the dead and live zero point.
- Move valve to end position OPEN.
- Set potentiometer "max." to end value 20 mA.
- Approach end position CLOSED anew and check minimum value (0.1 mA or 4.1 mA). If necessary, correct the setting.



If the maximum value cannot be reached, the selection of the reduction gearing must be checked.


17.2 Setting 3- / 4- wire system 4 - 20 mA

- Connect voltage to electronic position transmitter.
- Move valve to end position CLOSED.
- Pull off indicator disc.
- Connect ammeter for 0 20 mA to measuring points (figure 18).



The circuit (external load) must be connected (observe max. load R_B), or the appropriate poles at the terminals (refer to wiring diagram) must be linked, otherwise no value can be measured.

- Turn potentiometer (E2) counterclockwise until stop is felt.
- Turn potentiometer (E2) slighly back.




- Turn potentiometer "0" clockwise until output current starts to increase.
- Turn back potentiometer "0" until a residual current of approx. 0.1 mA is reached.
- Move valve to end position OPEN.
- Set potentiometer "max." to end value 16 mA.
- Move valve to end position CLOSED.
- Set potentiometer "0" from 0.1 mA to initial value 4 mA. This results in a simultaneous shift of the end value by 4 mA, so that the range is now 4 – 20 mA.
- Approach both end positions anew and check setting. If necessary, correct the setting.



If the maximum value cannot be reached, the selection of the reduction gearing must be checked.

18. Setting the mechanical position indicator

- Place indicator disc on shaft.
- Move valve to end position CLOSED.
- Turn lower indicator disc (figure 19) until symbol CLOSED is in alignment with the mark on the cover (figure 20).
- Move actuator to end position OPEN.
- Hold lower indicator disc in position and turn upper disc with symbol OPEN until it is in alignment with the mark on the cover.



The indicator disc turns approx. 180° for a swing angle of 90° .

19. Closing the switch compartment

- Clean sealing faces of housing and cover
- Check whether O-ring is in good condition.
- Apply a thin film of non-acidic grease to the sealing faces.
- Replace cover on switch compartment and fasten bolts evenly crosswise.



Check the part-turn actuator for damage to paint finish. If damage to paint-finish has occurred after mounting, it has to be touched up to avoid corrosion. **20.** Setting the operating time For part-turn actuators with 1-phase AC motors, the operating time can be adjusted.




Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules.

- Remove motor cover (figure 21).
- Set required operating time with potentiometer (figure 22).
- Clean sealing faces of housing and motor cover
- Check whether O-ring is in good condition.
- Apply a thin film of non-acidic grease to the sealing faces.
- Fit and fasten motor cover.

(For enclosure protection IP 68, the motor cover is additionally sealed with thread sealing material)



Check the part-turn actuator for damage to paint finish. If damage to paint-finish has occurred after mounting, it has to be touched up to avoid corrosion.






Table 6: Operating times for 90°	
SG 05.1	5.6 to 45 seconds
SG 07.1	11 to 90 seconds
SG 10.1	11 to 90 seconds
SG 12.1	22 to 180 seconds

21. Enclosure protection IP 68 (option)

Definition	 According to DIN EN 60 259, the conditions for meeting the requirements of enclosure protection IP 68 are to be agreed between manufacturer and user. AUMA actuators and controls in enclosure protection IP 68 meet the following requirements according to AUMA: Duration of submersion in water max. 72 hours Head of water max. 6 m Up to 10 operations during submersion Modulating duty is not possible during submersion Enclosure protection IP 68 refers to the interior of the actuators (motor, gearing, switch compartment, controls, and terminal compartment).
Inspection	AUMA actuators and controls in enclosure protection IP 68 undergo a routine testing for tightness in the factory.
Cable glands	 For the entries of the motor and control cables, appropriate cable glands in enclosure protection IP 68 must be used. The size of the cable glands must be suitable for the outside diameter of the cables, refer to recommendations of the cable gland manufacturers. As standard, actuators and controls are delivered without cable glands. For delivery, the threads are sealed with plugs in the factory. When ordered, cable glands can also be supplied by AUMA at an additional charge. For this, it is necessary to state the outside diameter of the cables. The cable glands must be sealed against the housing at the thread with an O-ring. It is recommended to additionally apply a liquid sealing material (Loctite or similar).
Commissioning	 When commissioning, the following should be observed: Sealing faces of housing and covers must be clean O-rings of the covers must not be damaged A thin film of non-acidic grease should be applied to sealing faces Covers should be tightened evenly and firmly
After submersion	 Check actuator. In case of ingress of water, dry actuator correctly and check for proper function.

22. Applications in Ex zone 22 (option)

Part-turn actuators of type range SG 05.1 - SG 12.1/SGR 05.1 - SGR 12.1 in versions AUMA NORM basically meet the requirements for applications in dust hazardous locations of ZONE 22, in compliance with the ATEX directive 94/9/EC.

The actuators are designed to meet enclosure protection IP 67 or IP 67 and meet the requirements of EN 50281-1-1:1998 section 6 – Electrical apparatus for use in presence of combustible dust hazards, requirements for electrical equipment of category 3 –protected by enclosures. To comply with all requirements of EN 50281-1-1: 1998, the following points must imperatively be observed:

- In compliance with the ATEX directive 94/9/EC, the part-turn actuators must be equipped with an additional identification – II3D IP6X T150°C.
- The maximum surface temperature of the actuators, based on an ambient temperature of + 40 °C in accordance with EN 50281-1-1 section 10.4, is 150 °C. In accordance with section 10.4, an increased dust deposit on the equipment was not considered for the determination of the max. surface temperature.
- The correct connection of the thermoswitches or the PTC thermistors, as well as the fulfilment of the type of duty and the technical data are prerequisites for compliance with the maximum surface temperature of part-turn actuators.
- The connection plug may only be plugged in or pulled out when actuator and controls are disconnected from the mains.
- The cable glands used have also to meet the requirements of category II3D and must at least comply with enclosure protection IP 67.
- The actuators must be connected by means of an external ground connection (accessory part) to the potential compensation or integrated into a grounded piping system.
- As a general rule, the requirements of EN 50281-1-1 must be respected in dust hazardous locations. During commissioning, service, and maintenance, respective special care as well as qualified and trained personnel is required for the safe operation of part-turn actuators.

23.	Maintenance	After maintenance, check part-turn actuator for damage to paint finish. If damage to paint-finish has occurred after mounting, it has to be touched up to avoid corrosion. Original paint in small quantities can be supplied by AUMA.
		AUMA part-turn actuators require very little maintenance. Precondition for reliable service is correct commissioning.
		Seals made of elastomers are subject to ageing and must therefore regu- larly be checked and, if necessary, be exchanged.
		It is also very important that the O-rings at the covers are placed correctly and cable glands fastened firmly to prevent ingress of dirt or water.
		We recommend additionally:
		 If rarely operated, perform a test run about every 6 months. This ensures that the actuator is always ready to operate. Approximately six months after commissioning and then every year check bolts between part-turn actuator and valve/gearbox for tightness. If required, tighten applying the torques given in table 1, page 9.
24.	Lubrication	AUMA part-turn actuators are filled with grease for lifetime. A change of grease or re-lubrication is not necessary.

25. Disposal and recycling

AUMA actuators have an extremely long lifetime. However, they have to be replaced at one point in time.

The actuators have a modular design and may therefore easily be disassembled, separated, and sorted according to materials, i.e.:

- electronic scrap
- various metals
- plastics
- greases and oils

The following generally applies:


- Collect greases and oils during disassembly. As a rule, these substances are hazardous to water and must not be released into the environment.
- See disassembled material to a sound disposal or to separate recycling according to materials.
- Observe the national regulations for waste disposal.

26. Service

AUMA offers extensive services such as maintenance and inspection for actuators. Addresses of AUMA offices and representatives can be found on page 36 and on the Internet (www.auma.com).

Notes

27. Spare parts list Multi-turn actuator SG(R) 05.1 - SG(R) 12.1 with plug/ socket connector



Note:

Please state type and commission no. of the actuator (see name plate) when ordering spare parts. Delivered spare parts may slightly vary from the representation in these instructions.

No.	Туре	Designation	No.	Туре	Designation	
1	E	Housing	36.5	В	Mechanical position indicator	
2.0	В	Worm shaft assly.	36.6*	В	Blinker transmitter including pins at wires	
2.4	E	End stop nut (included in sub-assembly 2.0)	50.0		(without impulse disc and insulation plate)	
3.0	В	Manual drive worm assly.	36.10	E	Cover plate	
4.0	В	Worm wheel	38.0	В	Pin carrier (without pins)	
5.0	В	Mounting flange assly.	38.2.2	В	Pin for motor	
10.0	В	End stop assly.	38.2.3	В	Pin for controls	
14	E	Coupling	38.2.4	В	Wire for protective earth	
16	E	Сар	39.0	В	Plug cover assly.	
17.0	В	Torque finger assly.	39.2	в	Socket carrier	
21.0	В	Limit drive finger assly.	39.2	D	(complete with sockets)	
29.0	В	Manual drive bearing assly.	39.2.2	в	Socket for motor	
32.0	В	Planetary gearing assly.	39.2.2	D	(included in sub-assembly 39.2)	
34.0	В	Motor assly.	39.2.3	в	Socket for control	
34.22	В	Motor plug pin carrier (without pins)	39.2.3		(included in sub-assembly 39.2)	
34.23	В	Pin for motor	39.2.4	В	Socket for protective earth (included in sub-assembly 39.2)	
34.24	В	Pin for thermoswitch	40	В	Handwheel assly.	
34.7	В	Motor brake	40.043	E	Cap assly.	
34.8	В	Motor electronic board	40.43	В	Ball handle assly.	
34.9	В	Cover plate	41	В	Motor plug, socket assly.	
35.0	В	Cover assly.	152.1*	В	Potentiometer (without slip clutch)	
36.0	В	Control unit assly. without switches	152.2*	В	Slip clutch for potentiometer	
36.1	В	Torque switching head	153.0*	В	Electronic position transmitter (RWG)	
36.2	В	Heater	153.1*	В	Potentiometer for RWG (without slip clutch)	
36.3.1	В	Stud bolt for switches	153.2*	В	Slip clutch for RWG	
		Switch for limit/ torque switching	153.3*	В	Electronic board RWG	
36.3.2	В	(including pins at wires)	S 1	S	Seal kit (small)	
36.3.4	E	Spacer	S 2	S	Seal kit (large)	

EC - Declaration of Conformity according to the directive of the Council for the approximation of the laws of the Member States re- lating to the EMC Directive (89/336/EEC)and the Low Voltage Equipment Directive (73/23/EEC)	AUMA part-turn actuators of the type ranges SG 05.1 - SG 12.1 in versions AUMA NORM, AUMA SEMIPACT, AUMA MATIC and AUMATIC	are designed and produced to be installed on industrial valves. Messrs. AUMA RIESTER GmbH & Co. KG as the manufacturer declares herewith, that the above mentioned electric AUMA part-turn actuators are in compliance with the following directives:	 Directive on Electromagnetic Compatibility (EMC) (89/336/EEC) Low-Voltage Equipement Directive (73/23/EEC) The compliance testing of the devices was based on the following standards: 	a) concerning the Directive on Electromagnetic Compatibility EN 61000-6-4: 08/2002 EN 61000-6-2: 08/2002 EN 61800-3: 02/2001	b) concerning the Low-Voltage Equipment Directive EN 60204-1 EN 60034-1 EN 50178	BUIMB AUMA RIESTER GmbH & Co. KG Auma RIESTER GmbH & Co. KG Armaturen- und Maschinenantriebe P.O. Box 13 62 •D- 79373 Muellheim / Baden Tei 07631 / 809-0 • Fax 07631 / 809-250 Tei 07631 / 809-0 • Fax 07631 / 809-250 Tei 07631 / 809-0 • Fax 07631 / 809-250 Tei 07631 / 809-0 • Fax 07631 / 809-250
Declaration of Incorporation according to EC - Machinery Directive 98/37/EC article 4 paragraph 2 (Annex II B) AUMA part-turn actuators of the type ranges	SG 05.1 - SG 12.1 SG Ex 05.1 - SG 12.1 SG Ex 05.1 - SG Ex 12.1 SG ExC 05.1 - SG ExC 12.1 in versions AUMA NORM, AUMA SEMIPACT, AUMA MATIC or AUMATIC	are designed and produced to be installed on industrial valves. Messrs. AUMA RIESTER GmbH & Co. KG as manufacturer declares herewith, that when designing the above mentioned electric AUMA part-turn actuators the following standards were anolied:	EN ISO 12100-1 EN 60034-1 EN ISO 12100-2 EN ISO 5211 EN 60 204-1	AUMA part-turn actuators covered by this Declaration must not be put into service until the entire machine, into which they are incorporated, has been declared in conformity with the provisions of the Directive.	auma* Müllhejg, February 09 th , 2005	AUMA RIESTER GmbH & Co. KG Amachinemaninebe Amachinemaninebe Tel 07831 / 809-0• Fax 07631 / 809-250 Tel 07831 / 809-0• Fax 07631 / 809-250

Declaration of Conformity and Declaration of Incorporation 28.

34 **auma**

A Ambient temperature	6	
C Certificate of Conformity Corrosion protection	34 7,28	
D Declaration of Incorporation Delay time DUO limit switching	34 10 17	
E Electrical connection Electronic position transmitter RWG 2-wire system 3-/ 4-wire system Enclosure protection IP 68 End stops SG on ball valves SG on butterfly valves	10 21 22 23 26 12 13 12	
F Fitting the ball handle	7	
H Handwheel Heater	8 11	
I Indicator disc	24	

L Limit switches Limit switching Lubrication	11 16,17 28
M Maintenance Manual operation Mechanical position indicator Motor protection Mounting to valve/ gearbox	4 8 24 11 9
N Name plate	32
O Operating time	25
P Packaging Position indicator Position transmitter RWG Potentiometer PTC thermistors R Pamata indication	7 24 21 20 11
Remote indication	20,21

S Safety instructions Service Spare parts list Storage Swing angle	4 29 32 7 14
T Tandem switches Technical data Test run Thermoswitches Torque setting Transport Tripping torque Type of duty	11 5 19 11 18 7 18 5

Information also available on the Internet:

Terminal plan, inspection records and further actuator information can be downloaded directly from the Internet by entering the order no. or COMM. no. (refer to name plate). Visit us at: http://www.auma.com



Jolutions for a world in motion.

Europe AUMA Riester GmbH & Co. KG Factory Müllheim DE-79373 Müllheim Tel +49 7631 809 - 0 Fax +49 7631 809 - 250 riester@auma.com www.auma.com Factory Ostfildern-Nellingen DE-73747 Ostfildern Tel +49 711 34803 - 3000 Fax +49 711 34803 - 3034 riester@wof.auma.com Service Centre Cologne **DE-50858 Köln** Tel +49 2234 20379 - 00 Fax +49 2234 20379 - 99 Service@sck.auma.com Service Centre Magdeburg DE-39167 Niederndodeleben Tel +49 39204 759 - 0 Fax +49 39204 759 - 19 Service@scm.auma.com Service Centre Bavaria DE-85748 Garching-Hochbrück Tel +49 89 329885 - 0 Fax +49 89 329885 - 18 Riester@scb.auma.com North Office, Ship building sector DE-21079 Hamburg Tel +49 40 791 40285 Fax +49 40 791 40286 Stephan.Dierks@auma.com North Office, Industry

Tel +49 5167 504 Fax +49 5167 504 Fax +49 5167 565 Erwin. Handwerker@auma.com East Office **DE-39167 Niederndodeleben** Tel +49 39204 75980 Fax +49 39204 75980 Claus.Zander@auma.com

West Office **DE-45549 Sprockhövel** Tel +49 2339 9212 - 0 Fax +49 2339 9212 - 15 Karlheinz.Spoede@auma.com SautholWeat Office

SoutheWest Office **DE-69488 Birkenau** Tel +49 6201 373149 Fax +49 6201 373150 Dieter.Wagner@auma.com

Württemberg Office DE-73747 Ostfildern Tel +49 711 34803 80 Fax +49 711 34803 81 Siegfried.Koegler@wof.auma.com Baden Office DE-76764 Rheinzabern

Tel +49 7272 76 07 - 23 Fax +49 7272 76 07 - 24 Wolfgang.Schulz@auma.com Power plant sector

DE-79373 Müllheim Tel +49 7631 809 192 Fax +49 7631 809 294 Klaus.Wilhelm@auma.com Büro Bavaria **DE 92365** Touran (Miodorb

DE-93356 Teugn/Niederbayern Tel +49 9405 9410 24 Fax +49 9405 9410 25 Mathias.Jochum@auma.com AUMA Armaturenantriebe GmbH AT-2512 Tribuswinkel Tel +43 2252 82540

Fax +43 2252 8254050 office@auma.at AUMA (Schweiz) AG CH-8965 Berikon Tel +41 566 400945 Fax +41 566 400948 RettichP.ch@auma.com AUMA Servopohony spol. s.r.o. CZ-10200 Praha 10 Tel +420 272 700056 Fax +420 272 704125 auma-s@auma.cz OY AUMATOR AR FI-02270 Espoo Tel +35 895 84022 Fax +35 895 8402300 auma@aumator.fi AUMA France FR-95157 Taverny Cédex Tel +33 1 39327272 Fax +33 1 39321755 stephanie.vatin@auma.fr www.auma.fr AUMA ACTUATORS Ltd. GB- Clevedon North Somerset BS21 6QH Tel +44 1275 871141 Fax +44 1275 875492 mail@auma.co.uk AUMA ITALIANA S.R.L. **IT-20023 Cerro Maggiore Milano** Tel +39 0331-51351 Fax +39 0331-517606 info@auma.it www.auma.it AUMA BENELUX B V NL-2314 XT Leiden Tel +31 71 581 40 40 Fax +31 71 581 40 49 office@benelux.auma.com AUMA Polska PL-41-310 Dabrowa Górnicza Tel +48 32 26156 68 Fax +48 32 26148 23 R.Ludzien@auma.com.pl www.auma.com.pl AUMA Priwody OOO RU-141400 Moscow region Tel +7 095 221 64 28 Fax +7 095 221 64 38 aumarussia@auma.ru www.auma.ru ERICHS ARMATUR AB SE-20039 Malmö Tel +46 40 311550 Fax +46 40 945515 info@erichsarmatur.se www.erichsarmatur.se GRØNBECH & SØNNER A/S DK-2450 København SV Tel +45 33 26 63 00 Fax +45 33 26 63 21 GS@g-s.dk www.g-s.dk IBEROPLAN S.A ES-28027 Madrid Tel +34 91 3717130 Fax +34 91 7427126 iberoplan@iberoplan.com D. G. Bellos & Co. O.E. **GR-13671** Acharnai Athens Tel +30 210 2409485 Fax +30 210 2409486 info@dgbellos.gr SIGURD SØRUM A. S.

NO-1301 Sandvika Tel +47 67572600 Fax +47 67572610 post@sigurd-sorum.no NDUSTRA PT-2710-297 Sintra Tel +351 2 1910 95 00 Fax +351 2 1910 95 99

jpalhares@tyco-valves.com

MEGA Endüstri Kontrol Sistemieri Tic. Ltd. Sti. **TR-06460 Övecler Ankara** Tel +90 312 472 62 70 Fax +90 312 472 62 74 megaendustri@megaendustri.com.tr CTS Control Limited Liability Company **UA-02099 Kiyiv** Tel +38 044 566-9371, -8427 Fax +38 044 566-9384 v_polyakov@cts.com.ua

Africa

AUMA South Africa (Pty) Ltd. **ZA-1560 Springs** Tel +27 11 3632880 Fax +27 11 8185248 aumasa@mweb.co.za A.T.E.C. **EG-Cairo** Tel +20 2 3596680 - 3590861 Fax +20 2 3556621 atec@intouch.com

America

AUMA ACTUATORS INC. US-PA 15317 Canonsburg Tel +1 724-743-AUMA (2862) Fax +1 724-743-4711 mailbox@auma-usa.com www.auma-usa.com

AUMA Chile Respresentative Office CL- La Reina Santiago de Chile Tel +56 2 821 4108 Fax +56 2 821 9252 aumachile @ adsl.tie.cl

LOOP S. A. **AR-C1140ABP Buenos Aires** Tel +54 11 4307 2141 Fax +54 11 4307 8612 contacto@loopsa.com.ar

Asvotec Termoindustrial Ltda. BR-13190-000 Monte Mor/ SP. Tel +55 19 3879 8735 Fax +55 19 3879 8738 atuador.auma@asvotec.com.br

TROY-ONTOR Inc. **CA-L4N 5E9 Barrie Ontario** Tel +1 705 721-8246 Fax +1 705 721-5851 troy-ontor@troy-ontor.ca MAN Ferrostaal de Colombia Ltda.

CO- Bogotá D.C. Tel +57 1 4 011 300 Fax +57 1 4 131 806 dorian.hernandez@manferrostaal.com

www.manferrostaal.com PROCONTIC Procesos y Control Automático EC-Quito Tel +593 2 292 0431 Fax +593 2 292 2343 info@procontic.com.ec

IESS DE MEXICO S. A. de C. V. MX-C.P. 02900 Mexico D.F. Tel +52 55 55 561 701 Fax +52 55 53 563 337 informes@iess.com.mx PASSCO Inc.

PR-00936-4153 San Juan Tel +18 09 78 77 20 87 85 Fax +18 09 78 77 20 87 85 Fax +18 09 78 77 31 72 77 Passco@ptc.net Suplibarca VE- Maracaibo Estado, Zulia Tel +58 261 7 552 667 Fax +58 261 7 532 259

Fax +58 261 7 532 259 suplibarca@intercable.net.ve Asia



AUMA (INDIA) PRIVATE LIMITED IN-560 058 Bangalore Tel +91 80 2839 4655 Fax +91 80 2839 2809 info@auma.co.in Www.auma.co.in AUMA JAPAN Co., Ltd. JP-210-0848 Kawasaki-ku, Kawasaki-shi Kanagawa Tel +81 44 329 1061 Fax +85 6 481262 AUMA ACTUATORS (Singapore) Pte Ltd. SG-569551 Singapore Tel +85 6 4818269 sales@auma.com.sg Www.auma.com.sg AUMA Middle East Rep. Office AE- Dubai Tel +971 4 3682720 Fax +971 4 3682721 auma@emirates.net.ae

PERFECT CONTROLS Ltd. HK- Tsuen Wan, Kowloon Tel +852 2493 7726 Fax +852 2416 3763 joeip@perfectcontrols.com.hk

DW Controls Co., Ltd. **KR-153-803 Seoul Korea** Tel +82 2 2113 1100 Fax +82 2 2113 1088/1089 sichoi@actuatorbank.com www.actuatorbank.com

AL-ARFAJ Eng. Company W. L. **KW-22004 Salmiyah** Tel +965 4817448 Fax +965 4817442 arfaj@qualitynet.net BEHZAD Trading Enterprises **QA-Doha** Tel +974 4433 236 Fax +974 4433 237 behzad@qatar.net.qa

Sunny Valves and Intertrade Corp. Ltd. TH-10120 Yannawa Bangkok Tel +66 2 2400656 Fax +66 2 2401095 sunnyvalves@inet.co.th

Top Advance Enterprises Ltd. **TW- Jhonghe City Taipei Hsien (235)** Tel +886 2 2225 1718 Fax +886 2 8228 1975 support@auma-taiwan.com.tw www.auma-taiwan.com.tw AUMA Beijing Representative Office **CN-100029 Beijing**

CN-100029 Beijing Tel +86 10 8225 3933 Fax +86 10 8225 2496 mailbox@auma-china.com www.auma-china.com

Australia

BARRON GJM Pty. Ltd. **AU-NSW 1570 Artarmon** Tel +61 294361088 Fax +61 294393413 info@barron.com.au www.barron.com.au

2005-11-03

auma

AUMA Riester GmbH & Co. KG P. O. Box 1362 D - 79373 Müllheim Tel +49 (0)7631/809-0 Fax +49 (0)7631/809 250 riester@auma.com www.auma.com AUMA Riester GmbH & Co. KG P. O. Box 1151 D - 73747 Ostfildern Tel +49 (0)711 / 34803 0 Fax +49 (0)711 / 34803 34 riester@wof.auma.com www.auma.com

For detailed information on AUMA products, refer to the Internet:

www.auma.com